

INSTRUCTIONS TO REPAIR CISTERN AGAINST DAMAGE DUE TO DRILLING.

Step 1 > Clean of the glue areas with sandpaper, available burrs on the surface must be removed on cistern and disk.



Go to step 2

Step 2) Cleaning of the areas to be pasted with Acetone on disk and cistern



Go to step 3

Step 3) Glue order with Heißklebepistole on plastic disk



Go to step 4

Step 4) Firmly pressing of the plastic disk



Go to step 5

Step 5) After 15min rinse box again with
water

Step 6) rinse box on density